OMEGA
PROLINE

REC-12
Deluxe Remote Keyless Entry System

Standard Features:

NEW! Stylish Transmitters! **NEW!** Programmable Features!
NEW! Auxillary Outputs! **NEW!** Domelight Supervision! **NEW!** Starter Interrupt!

 The REC-12 is a fully-featured and easily expandable keyless entry system with lock, two unlocks (for driver's door priority), trunk and 3rd channel outputs. This unit has flashing parking light and dome light relays built-in, and remote panic feature. Included is Omega's standard 5 pin main harness, secondary flashing light and base doorlock output harnesses. The REC-12 also includes a Blue Status Indicator Light, and plug-in Valet Switch. 39 programmable options offer great flexibilty and customization. Not included with this model, but within its capabilities, is multi-car operation.

Two Transmitters included: New design OEM-style 4-Button Transmitters with pictograph buttons.

Operations: Lock Button- Press and release to Lock doors. Press and hold to activate Remote Panic with locking doors (horn connection required).

Unlock Button - Press and release to Unlock doors. If driver door priority is configured, one press unlocks driver's door, second press unlocks all. Press and hold to activate Remote Panic with unlocking doors (horn connection required).

Trunk Button - Press and hold to activate trunk release.

III Button - Press and hold to activate the 3rd channel output.

How to Code the Transmitters: Turn "on" the ignition, then press the valet switch 5 times and wait for audible response (via horn honk). Press and release the Lock button on each transmitter to be coded (one at a time). The system will respond to each with an audible confirmation.

Omega part # **4410-07**

*OPTIONAL #**4410-07B** is Available For Multi-car functionality

MORE Programmable Features Options! The Omega REC-12 is extremely versatile, due to a comprehensive array of 12 programmable features, with many of the individual Features offering as many as four setting choices.

Programmable Features

How to program: Turn the ignition ON, then OFF. Press the Valet Swtch **5** times (the horn will honk; the Status LED lights **Blue**). Then select the desired feature by pressing the Valet Swich the same number of times as the feature number. After the system honks the horn the same number back, choose the feature's setting by pressing the transmitter buttons: the **Lock** button (L); **Unlock** button (U); **Trunk** button (2) or **III** button (3).

Feature Programming:	Ignition on, off, press valet 5 times (Horn honks, status light turns on)			Bold = Default setting
# Feature	Lock Button	Unlock button	Trunk button	"…" button
1 Lock 90 Sec After Ign Off	**ON**	OFF		
2 Lock 90 Sec After Unlock	**ON**	OFF		
3 Ign Controlled Lock/Unlock	**Lock & Unlock**	Lock Only	Unlock Only	OFF
4 Unlock w/ Trunk Release	**ON**	OFF		
5 Lock/Unlock Pulse Time	**0.8 Sec**	3 Sec	Dbl Unlock	
6 Domelight Relay Function	**Domelight**	4th Ch Pulse	4th Ch Latch	Light Flash
7 Light Relay Function	**Light Flash**	5th Ch Pulse	5th Ch Latch	Horn Honk
8 Confirmation Chirps	**Quiet**	Loud	On Demand	OFF
9 90 Sec Auto Starter Disable	**After Ign Off**	After Unlock	Ign Off & Unlock	OFF
10 Anti-Carjacking	**Ignition**	Remote	Ign. & Remote	OFF
11 Lights On After Unlock	**ON**	OFF		
12 "…" Button Function	**3rd Ch Pulse**	3rd Ch Latch	3rd Ch - 30 Sec	Panic

Full System Reset

You can return all programmable features to their factory default by entering features programming. Then, immediately press the **LOCK** and **UNLOCK** buttons simultaneously. The system will respond with 3 horn honks.

Omega REC-12

Orange wire- Negative (-) Starter Interrupt output.

Gray wire- Negative (-) output for trunk release.

Yellow wire- Ignition (+) 12 volts.

Black wire- (-) Chassis ground.

Red wire- Constant (+) 12 volts.

(-) Yellow/Green - OEM Alarm Disarm Output

(-) Brown - Horn Output

(+/-) White - Parking Light Polarity Select Input

(-) Pink - 3rd Channel Output

(+/-) White - Parking Light Output

Pair of White/Black Wires- Dome Light Input/ Output

(+) Output (for relay COILS only)

(-) Unlock #1 Pulse

(-) Unlock #2 Pulse

(-) Lock Pulse

Slide Bracket For Clip-on Accessories

Valet Switch Port

Doorlock Output Port

Main Connector Port

Secondary Connector Port

LED Status Light Port

Fuse

Fuse

Fuse

Black Antenna Wire (Stretch out Fully for Best Range)

Slide Bracket For Clip-on Accessories